



**TOPNOTCH<sup>®</sup>**  
SUB-FLOORING

## Installation Instructions

- 1) Protect panels from rain prior to installation. If outside, store off the ground and cover with plastic or a tarpaulin that is loose enough to allow for air circulation.
- 2) In glued-and-nailed applications, layout only enough glue for 1 or 2 panels at a time. Use only glues conforming to Performance Specification AFG-01.
- 3) Apply a small bead of glue (about 1/8" wide) in the groove of the panels prior to installing the next row.
- 4) Install the panels across a minimum of 3 supports and stagger end joints in adjacent rows.
- 5) Do not overdrive panels together. The tongue-and-groove joint is self spacing, so lightly tap the panels together using a block to protect groove edges.
- 6) ALWAYS allow a 1/8" gap at the ends and edges of all panels to allow for expansion.
- 7) Fasten panels using 8d ring-shank nails, or other code-approved fasteners.
- 8) Install fasteners beginning 3/8" from panel corner and then 6" OC along the panel edges, and at 12" OC along center supports
- 9) Be sure to place all perimeter fasteners 3/8" back from the nearest panel edge.
- 10) Fasten panels completely while the glue is still wet to ensure maximum performance.

### TECHNICAL SERVICES/SALES INFORMATION

Call LP customer service or visit our web site for more information on LP TopNotch Sub-Flooring

Customer Service:  
800.648.6893  
[www.lpcorp.com](http://www.lpcorp.com)

Sales Office:  
Conroe, Texas 800.964.6310

---

**Cal. Prop 65 Warning: Use of this product may result in exposure to wood dust, known to the State of California to cause cancer.**

---